

INSTALLATION FOR PART NO. 1317 2009 FORD F-150 GRILLGUARD

(revised model)

You will need:

8 - $\frac{1}{2}$ x $\frac{1}{2}$ bolts	12 - $\frac{1}{2}$ nut
4 - $\frac{1}{2}$ x 2 bolts	12 - $\frac{1}{2}$ lock washer
22 - $\frac{1}{2}$ flat washer	2 - $\frac{3}{16}$ x 2 square washer

Step 1: Place bottom bracket under tow hook as shown.

Step 2: If the truck has no tow hooks, you need to make an opening for the bottom brackets. There should be tow holes on bottom of the frame where you must bolt on the bottom bracket as shown.

Step 3: Insert the "L" bracket through the factory front bumper holes and bolt it to the grill guard tab as shown below.

Step 4: Once the grill guard is in place, the bottom bracket should be on the inside of the upright and the top bracket should be on the bottom of the tab.

Step 5: Align grill guard and tighten all bolts.

