

2003-2005 DODGE 2500/3500
FRONT END REPLACEMENT
#2237 & #2238

1. Remove front bumper.
2. Place front end replacement on outside of frame and bolt on through the frame as shown.

