

GAGE INSTALLATION SHEET

FITS PART #2351, 2352P, 2353P, 2354P, 2355P, 2356P, 2357P, 2358

1. Remove factory bumper.
2. Bolt support bracket to strut bracket on side of the frame as shown.
3. Mount bumper to factory bumper bracket. Insert bolt (1/2" x 2") through bracket on bumper, factory bumper bracket, and support bracket.
4. Remove fog light from factory bumper. Place them on the replacement light brackets.
5. Check alignment on the replacement bumper and tighten bolts.
6. You may need to periodically retighten bolts.

